

How to judge whether it is the controller hall fault or the motor hall fault?



When the fault indicator light of controller flashes **13** times, it reports a "hall fault" error. To judge whether the motor hall is broken or the controller, you could use the following ways:

- 1- Power off the controller, **disconnect** the plugs of the controller and the motor hall.
- 2- Find a tweezers or a wire, connect one end of the wire to the **negative pole(black wire)** of the controller hall connector, and the other end to the yellow one.



© 2018 stock.kuhong.com

or



3- Power on the controller, if the indicator light no longer flashes **13** times at this time (no flashing or the flashing times is not **13** times), it means the controller is no problem, there is something wrong with the motor.

If the indicator light flashes **13** times, it means the controller is broken, contact our manufacturer for maintenance.